


14.10: Titration Curves


When an acid is titrated with a base, there is typically a sudden change in the pH of the solution at the **equivalence point** (where the amount of titrant added equals the amount of acid originally present). If a few drops of indicator solution have been added, this sharp increase in pH causes an abrupt change in color, which is called the **endpoint** of the indicator. The actual magnitude of the jump in pH, and the pH range which it covers depend on the strength of both the acid and the base involved, and so the choice of indicator can vary from one titration to another. To learn how to choose an appropriate indicator, we need to study in some detail the variation of pH during a titration.

For reference as you read this section, cm^3 is equivalent to mL.



First we shall consider titration of a strong acid such as HCl with a strong base such as NaOH. Suppose we place 25.00 cm^3 (mL) of 0.10 M HCl solution in a flask and add 0.10 M NaOH from a buret. The pH of the solution in the flask varies with added NaOH, as shown in Figure 1a. The pH changes quite slowly at the start of the titration, and almost all the increase in pH takes place in the immediate vicinity of the endpoint.

The pH change during this titration is caused by the proton-transfer reaction



which occurs as hydroxide ions are added from the buret. Though hydronium ions are being consumed by hydroxide ions in the early stages of the titration, the hydronium-ion concentration remains in the vicinity of 10^{-1} or $10^{-2} \text{ mol L}^{-1}$. As a result, the pH remains in the range 1 to 2. As an example of this behavior let us consider the situation halfway to the endpoint, i.e., when exactly 12.50 cm^3 of 0.10 M NaOH have been added to 25.00 cm^3 (mL) of 0.10 M HCl in the flask. The amount of hydronium ion has been reduced at this point from an original 2.5 mmol to half this value, 1.25 mmol . At the same time the volume of solution has increased from 25 cm^3 to

$(25 + 12.50) \text{ cm}^3 = 37.50 \text{ cm}^3$. Therefore, the hydronium-ion concentration is $1.25 \text{ mmol} / 37.50 \text{ cm}^3 = 0.0333 \text{ mol L}^{-1}$, and the resultant pH is 1.48. Though the titration is half completed, this is not very different from the initial pH of 1.00.

The pH of the solution in the flask will only change drastically when we reach that point in the titration when only a minute fraction of the hydronium ions remain unconsumed, i.e., as we approach the endpoint, seen on the graph. Only then will we have reduced the hydronium-ion concentration by several powers of 10, and consequently increased the pH by several units. When 24.95 cm^3 of base have been added, we are only 0.05 cm^3 (approximately one drop) short of the endpoint. At this point $24.95 \text{ cm}^3 \times 0.10 \text{ mmol cm}^{-3} = 2.495 \text{ mmol}$ hydroxide ions have been added. These will have consumed 2.495 mmol hydronium ions, leaving $(2.5 - 2.495) \text{ mmol} = 0.005 \text{ mmol}$ hydronium ions in a volume of 49.95 cm^3 . The hydronium-ion concentration will now be:

$$[\text{H}_3\text{O}^+] = \frac{0.005 \text{ mmol}}{49.95 \text{ cm}^3} = 1.00 \times 10^{-4} \text{ mol L}^{-1}$$

giving a pH of 4.00. Because almost all the hydronium ions have been consumed, only a small fraction (one five-hundredth) remains and the volume of solution has nearly doubled. This reduces the hydronium-ion concentration by a factor of 10^{-3} , and the pH increases by three units from its original value of 1.00.

When exactly 25.00 cm^3 of base have been added, we have reached the theoretical equivalence point, and the flask will contain 2.5 mmol of both sodium and chloride ions in 50 cm^3 of solution; i.e., the solution is 0.05 M NaCl. Furthermore its pH will be *exactly* 7.00, as seen on the graph, since neither the sodium ion nor the chloride ion exhibits any appreciable acid-base properties.

Immediately after this equivalence point the addition of further NaOH to the flask results in a sudden increase in the concentration of hydroxide ions, since there are now virtually no hydronium ions left to consume them. Thus even one drop (0.05 cm^3) of base added to the equivalence point solution adds 0.005 mmol hydroxide ions and produces a hydroxide-ion concentration of $0.005 \text{ mmol} / 50.05 \text{ cm}^3 = 1.00 \times 10^{-4} \text{ mol L}^{-1}$. The resultant $\text{pOH} = 4.00$, and the $\text{pH} = 10.00$. The addition of just two drops of base results in a pH jump from 4.00 to 7.00 to 10.00. This rapid rise causes the indicator to change color, so the **endpoint** matches the **equivalence point** if the indicator is chosen properly.

Titration of a strong base with a strong acid can be handled in essentially the same way as the strong acid-strong base situation we have just described.

✓ Example 14.10.1 : pH During Titration

Suppose that 25.00 cm^3 of 0.010 M KOH is titrated with 0.01 M HNO_3 . Find the pH of the solution in the flask (a) before any HNO_3 is added; (b) halfway to the endpoint; (c) one drop (0.05 cm^3) before the endpoint; (d) one drop after the endpoint.

Solution:

a) Since KOH is a strong base, $[\text{OH}^-] = 0.010 = 10^{-2}$. Thus $\text{pOH} = 2$ and $\text{pH} = 14 - 2 = 12$ **b)** Halfway to the endpoint means that half the OH^- has been consumed. The original amount of OH^- was

$$\begin{aligned} n_{\text{OH}^-} &= V_{\text{NaOH}} \times c_{\text{NaOH}} & (14.10.1) \\ &= 25.00 \text{ cm}^3 \times \frac{0.010 \text{ mmol}}{1 \text{ cm}^3} & (14.10.2) \\ &= 0.25 \text{ mmol} & (14.10.3) \end{aligned}$$

so the amount remaining is 0.125 mmol OH^- . It must have required 0.125 mmol HNO_3 to consume the other 0.125 mmol OH^- , and so the volume of HNO_3 added is

$$\begin{aligned} V_{\text{HNO}_3} &= \frac{n_{\text{HNO}_3}}{c_{\text{HNO}_3}} & (14.10.4) \\ &= \frac{0.125 \text{ mmol}}{0.010 \text{ mmol cm}^{-3}} & (14.10.5) \\ &= 12.50 \text{ cm}^3 & (14.10.6) \end{aligned}$$

The total volume of solution is thus $(12.50 + 25.00) \text{ cm}^3 = 37.50 \text{ cm}^3$, and

$$\begin{aligned} [\text{OH}^-] &= \frac{0.125 \text{ mmol}}{37.50 \text{ cm}^3} & (14.10.7) \\ &= 3.33 \times 10^{-3} \text{ mmol cm}^{-3} & (14.10.8) \\ &= 3.33 \times 10^{-3} \text{ mol L}^{-1} & (14.10.9) \end{aligned}$$

$\text{pOH} = -\log(3.33 \times 10^{-3}) = 2.48$ and $\text{pH} = 14 - 2.48 = 11.52$ **c)** When 24.95 cm^3 of HNO_3 solution has been added, the amount of H_3O^+ added is

$$\begin{aligned} n_{\text{H}_3\text{O}^+} &= 24.95 \text{ cm}^3 \times \frac{0.010 \text{ mmol}}{1 \text{ cm}^3} & (14.10.10) \\ &= 0.2495 \text{ mmol} & (14.10.11) \end{aligned}$$

This would consume an equal amount of OH^- , and so the amount of OH^- remaining is $(0.2500 - 0.2495) \text{ mmol} = 0.0005 \text{ mmol}$. Thus

$$\begin{aligned} [\text{OH}^-] &= \frac{0.0005 \text{ mmol}}{(25.00 + 24.95) \text{ cm}^3} & (14.10.12) \\ &= 1.0 \times 10^{-5} \text{ mmol cm}^{-3} & (14.10.13) \\ &= 1.0 \times 10^{-5} \text{ mol L}^{-1} & (14.10.14) \end{aligned}$$

$\text{pOH} = 5.0$ and $\text{pH} = 9.0$ **d)** An excess of 0.05 cm^3 of acid will add

$$\begin{aligned} n_{\text{H}_3\text{O}^+} &= 0.05 \text{ cm}^3 \times \frac{0.010 \text{ mmol}}{1 \text{ cm}^3} & (14.10.15) \\ &= 5 \times 10^{-4} \text{ mmol} & (14.10.16) \end{aligned}$$

of H_3O^+ to a neutral solution whose volume is $(25.00 + 25.05) \text{ cm}^3 = 50.05 \text{ cm}^3$.

Thus

$$[\text{H}_3\text{O}^+] = \frac{5 \times 10^{-4} \text{ mmol}}{50.05 \text{ cm}^3} = 1 \times 10^{-5} \text{ mol L}^{-1}$$

$\text{pH} = 5$

Note:

In this case, because the solutions were one-tenth as concentrated as in the titration of HCl with NaOH worked out in the text, the jump in pH (from 9 to 5) at the endpoint is smaller.






Figure 14.10.1 *a*. In both cases these gray areas coincide with the vertical portion of the pH curve at the endpoint very nicely.

A wide choice of indicators like this is not possible for titrations involving weak acids or bases. When 25.00 cm³ of 0.10M CH₃COOH is titrated with 0.10M NaOH, for instance, there is a very much smaller change in pH at the equivalence point, as shown in Figure 1b, and the choice of indicators is correspondingly narrowed. The behavior of the pH in this case is very different from that of the titration of HCl with NaOH, because the acid-base reaction is different.

When CH₃COOH is titrated with NaOH, the OH⁻ ions consume CH₃COOH molecules according to the equation:



As a result, the solution in the titration flask soon becomes a buffer mixture with appreciable concentrations of the CH₃COO⁻ ion as well as its conjugate acid. The [H₃O⁺] and the pH are then controlled by the ratio of acid to conjugate base (equations 2 and 3 in the section on buffer solutions). When we are halfway to the endpoint, for example, [CH₃COOH] will be essentially the same as [CH₃COO⁻], and

$$[\text{H}_3\text{O}^+] = K_a \times \frac{[\text{CH}_3\text{COOH}]}{[\text{CH}_3\text{COO}^-]} \quad (14.10.17)$$

$$\approx K_a = 1.8 \times 10^{-5} \text{ mol L}^{-1} \quad (14.10.18)$$

while the pH will be given by the Henderson-Hasselbalch equation as

$$\text{pH} = \text{p}K_a + \log \frac{[\text{CH}_3\text{COOH}]}{[\text{CH}_3\text{COO}^-]} \quad (14.10.19)$$

$$\approx \text{p}K_a = 4.74 \quad (14.10.20)$$

Comparing this to the pH of 1.78 calculated above for the halfway stage in the titration of HCl, we find a difference of roughly three pH units. The effect of the buffering action of the CH₃COOH/ CH₃COO⁻ conjugate pair is thus to keep the pH some three units higher than before and hence to cut the jump in pH at the endpoint by approximately this amount.

Exactly at the equivalence point we no longer have a buffer mixture but a 0.05-M solution of sodium acetate. This solution is slightly basic, and its pH of 8.72 can be calculated from [equation 4 on the section covering the pH of weak base solutions](#). Beyond this equivalence point, the story is much the same as in the strong-acid case. Addition of even a drop (0.05cm^3) of excess base raises the OH^- concentration to 10^{-4}mol L^{-1} and the pH to 10. Of the three indicators which could be used in the titration of HCl, only one is useful for acetic acid. This is phenolphthalein, which changes color to the pinkish hue, as seen below, when in the pH range 8.3 to 10.0.



Figure 14.10.1 b, the color of methyl red would start changing after only about 4 cm^3 of base had been added!

The titration of a weak base with a strong acid also involves a buffer solution and consequently requires a more careful choice of indicator.

✓ Example 14.10.2 : Titration

For the titration of 25.00 cm^3 of 0.010 M NH_3 with 0.010 M HCl , calculate the pH (a) before any acid is added; (b) after 12.50 cm^3 of HCl has been added; (c) at the equivalence point; (d) after 30.00 cm^3 of HCl has been added.

Solution:

a) Before any acid is added, we have a solution of a weak base, and [equation 4 from the section on weak bases](#) applies:

$$[\text{OH}^-] = \sqrt{K_b c_b} \quad (14.10.21)$$

$$= \sqrt{1.8 \times 10^{-5}\text{ mol L}^{-1} \times 1.0 \times 10^{-2}\text{ mol L}^{-1}} \quad (14.10.22)$$

$$= 4.24 \times 10^{-4}\text{ mol L}^{-1} \quad (14.10.23)$$

$$\text{pOH} = -\log(4.24 \times 10^{-4}) = 3.37$$

$$\text{and pH} = 14 - 3.37 = 10.63$$

b) Since the concentrations of base and acid are equal, 12.50 cm^3 of HCl is enough to consume half the NH_3 , converting it to the conjugate acid NH_4^+ .

The Henderson-Hasselbalch equation may be used to obtain the pH of this buffer system, provided we use $\text{p}K_a(\text{NH}_4^+)$. Rearranging [equation 2 from the section on acid-base pairs and pH](#),

$$\text{p}K_a(\text{NH}_4^+) = 14 - \text{p}K_b(\text{NH}_3) \quad (14.10.24)$$

$$= 14 + \log(1.8 \times 10^{-5}) \quad (14.10.25)$$

$$= 14 - 4.74 = 9.26 \quad (14.10.26)$$

Since $[\text{NH}_4^+] \approx [\text{NH}_3]$

$$\text{pH} = \text{p}K_a + \log \frac{[\text{A}^-]}{[\text{HA}]} \quad (14.10.27)$$

$$= \text{p}K_a + \log \frac{[\text{NH}_3]}{[\text{NH}_4^+]} \quad (14.10.28)$$

$$\approx \text{p}K_a = 9.25 \quad (14.10.29)$$

c) At the equivalence point all the NH_3 has been converted to NH_4^+ , and so we have a solution of NH_4Cl . The volume of solution has doubled because 25.00 cm^3 of HCl was added, and so $c_{\text{NH}_4^+}$ must be half the original c_{NH_3} ; that is, $c_{\text{NH}_4^+} = 0.0005\text{ mol L}^{-1}$. $K_a(\text{NH}_4^+)$ is obtained from $K_b(\text{NH}_3)$ using [equation 1 from the section on acid-base pairs and pH](#):

$$K_a(\text{NH}_4^+) = \frac{K_w}{K_b(\text{NH}_3)} \quad (14.10.30)$$

$$= \frac{1.00 \times 10^{-14} \text{ mol}^2 \text{ L}^{-2}}{1.8 \times 10^{-5} \text{ mol L}^{-1}} \quad (14.10.31)$$

$$= 5.56 \times 10^{-10} \text{ mol L}^{-1} \quad (14.10.32)$$

Thus

$$[\text{H}_3\text{O}^+] = \sqrt{K_a c_a} \quad (14.10.33)$$

$$= \sqrt{5.56 \times 10^{-10} \text{ mol L}^{-1} \times 5.0 \times 10^{-3} \text{ mol L}^{-1}} \quad (14.10.34)$$

$$\text{text} = 1.67 \times 10^{-6} \text{ mol L}^{-1} \quad (14.10.35)$$

$$(14.10.36)$$

$$\text{pH} = -\log(1.67 \times 10^{-6}) = 5.78 \quad (14.10.37)$$

d) By adding an excess 5.0 cm³ of HCl we have added a strong acid to a solution which previously contained the very weak acid NH₄⁺. To a first approximation, then, we consider only H₃O⁺ produced by HCl.

$$[\text{H}_3\text{O}^+] = K_a \times \frac{5.0 \text{ cm}^3 \times 0.010 \text{ mol L}^{-1}}{55.00 \text{ cm}^3} \quad (14.10.38)$$

$$= 9.1 \times 10^{-4} \text{ mol L}^{-1} \quad (14.10.39)$$

$$(14.10.40)$$

$$\text{pH} = -\log(1.69.17 \times 10^{-4}) = 3.04 \quad (14.10.41)$$

The pH variation during titrations of strong and weak bases with strong acid are shown in Figure 14.10.2. In the case of the titration of 0.010 M NH₃ with 0.010 M HCl, methyl red, but not phenolphthalein, would be a suitable indicator. In general the best indicator for a given titration is the one whose pK_a most nearly matches the pH calculated at the theoretical endpoint.




Figure 14.10.2 Variation of pH during titration of strong and weak bases with strong acid: (a) 25.00 cm³ of 0.010 M KOH titrated with 0.010 M HNO₃; (b) 25.00 cm³ of 0.010 M NH₃ titrated with 0.010 M HCl. The pH ranges over which the indicators phenolphthalein (pH to 10.0) and methyl red (pH 4.2 to 6.2) change color are indicated in gray.

This page titled [14.10: Titration Curves](#) is shared under a [CC BY-NC-SA 4.0](#) license and was authored, remixed, and/or curated by [Ed Vitz](#), [John W. Moore](#), [Justin Shorb](#), [Xavier Prat-Resina](#), [Tim Wendorff](#), & [Adam Hahn](#).